



INSTALLATION GUIDE:

1. Excavate 900 wide x 500 deep.
2. First pour C35 concrete 200 deep (300 below finished floor level).
3. Anchor bolt and level gate.
4. Anchor posts to walls (optional).
5. Add ducts: Ø100 Power to motor, Ø50 Control to motor, Ø50 photocell post to post.
6. Terminate ducting and seal off. Check gate is level.
7. Second pour C35 concrete to F.F.L.



Avon Barrier Corporation Ltd.  
149 South Liberty Lane,  
Ashton Vale Trading Est.  
Bristol.  
BS3 2TL.  
UK.  
T: +44 (0)117 953 5252  
E: technical@avon-barrier.co.uk  
W: www.avon-barrier.co.uk

Drawing Title  
**SPEED  
GATE  
DOUBLE  
EXAMPLE**

A	NEW	M.J	30/6/08
ISSUE	REVISION	SIG.	DATE

3rd ANGLE PROJECTION	Tolerances	Used on	Drawn	Traced	Checked	Approved	Date	Scale
			M.J				6/08	NTS
IF IN DOUBT ASK	COMPUTER GENERATED DO NOT ALTER BY HAND	Material	Finish	REF. W.I.	Drawing No.	Sht.	of	Rev.
					SPG-102	1	1	A